

Installation Instructions

Mega Weight System:

- 1). Remove the original Magpul covers.
- 2). Install one of the Stealth Ballistics covers using original Magpul screws. Snug is tight enough.
- 3). Carefully insert the weight.
- 4). Install second Stealth Ballistics cover. Lead, to the extent possible, with the “top” of the triangle. When positively seated at top, the bottom screw holes should lightly snap into place.
- 5). Reinstall the original screws, being careful not to over tighten. Snug is tight enough.

The silver screws in the Stealth Ballistics covers have been pre-adjusted and should not require adjustment.